

Programmable Countdown Timers

Set machine times for delay on generator start, delay on transfer, delay on re-transfer and run on lines.



Test Mode Status Indication

Allows on/off load tests at routine service checks.



Keypad

For ease of programming and testing. Password protection is included.

System Status Indicators

Shows status of utility power, generating set and switch at all times.



LCD Display

Shows detailed status of system at all times for greater awareness and control.



Voltage Sensing Top

Allows for pole voltage sensing.



Bottom Gland Plate

Removable gland plate.



Solid Neutral Kit

Allows the connection of neutral cables from utility poles, generating set and load without having the neutral broken by the switch during transfer operations.



Wall Mounting

Panel is wall mounted for greater flexibility in positioning.



Padlockable

Switch can be padlocked in all three positions for added security and safety. Only possible in manual operation mode.



Manual Handle

Fully integrated handle for manual operation. Only available when door is open.



Auxiliary Contacts

Auxiliaryvolt free contacts for remotely monitoring the switch position.



Control Terminals

Terminals for remotely monitoring the system and remote start signal for uncomplicated connection to generating set.



Auxiliary Controls

Auxiliary inputs for automatic control, remote test on load and manual re-transfer.

